


SPARE PARTS LIST



KEY NO.	DESCRIPTION	QTY.
1	M8 Acorn Nut	4
2	M8 Washer	4
3	M8 x 60mm Carriage Bolt	4
4	Front Stabilizer	1
5	Spanner	1
6	Rear Stabilizer	1
7	Left Pedal	1
8	Right Pedal	1
9	Saddle Post	1
10	Handlebar Post	1
11	Handlebar	1
12	M8 x 16mm Screw	2
13	M8 Black Washer	2
14	Allen key with Screwdriver	1
15	M4 x 10mm Screw	8
16	M5 x 30mm Bolt	2
17	M5 Washer	6
18	M5 Nut	2
19	Leveling Cap	2
20	M6 x 25mm Eyebolt	2
21	Frame	1
22	Adjustment Knob	3
23	Sleeve	2
24	Resistance Knob	1
25	Saddle Carriage	1
26	Saddle	1
27	Carriage Cap	1
28	Flywheel	1
29	Flywheel Cover	2
30	Hub	1
31	Sprocket	1
32	Lock Ring	1

KEY NO.	DESCRIPTION	QTY.
33	M5 x 12mm Screw	6
34	M4 x 20mm Screw	5
35	Right Crank Arm/Sprocket	1
36	Bottom Bracket	1
37	Inner Chain Guard	1
38	Chain	1
39	Outer Chain Guard	1
40	Guard Cover	1
41	9mm x 12mm x 14mm Spacer	1
42	Square Plate	1
43	Stabilizer Cap	2
44	Upper Brake Cap	1
45	Compression Spring	1
46	Square Nut	1
47	Hex Nut	1
48	M6 Acorn Nut	1
49	Brake Pad Assembly	1
50	Brake Bracket	1
51	Isolator	1
52	Water Bottle Holder	1
53	M6 Locknut	2
54	Left Crank Arm	1
55	Crank Cap	2
56	M8 Flange Nut	2
57	M10 Flange Nut	2
58	M10 Washer	2
59	M5 x 10mm Screw	1
60	Sleeve	2
61	Console	1
62	Console Wire with Speed Sensor	1